

## Technical Bulletin

### **DESCRIPTION / FEATURES:**

#### **FLOOR MEDICS CRYSTAL:**

Is an evolution single step medium density quartz formulation designed to fill the surface with highly Nano resilient silicate quartz for Natural Stone, agglomerate and tiles. Maximizes the floors luster, excellence shine and durability. Without losing the slip resistance characteristics of Stone and Tiles surface.

Removes light scuffmarks and light scratches in the finish and provides a medium durable high luster.

#### **Single step, User friendly, Waterless system**

#### **■ USES:**

- Serpentine, Granite, Agglomerate Stone & Tiles.
- Porcelain & Ceramic Tiles, Other Compress & Quartz Stones.

#### **■ AVAILABLE SIZES:**

Crystal is available in 1Gallon bottle

#### **■ COVERAGE:**

Approximately 1000 sq.ft( 100 m<sup>2</sup>) per 1L depending on type of stone/tile and its finishes.

#### **■ METHOD OF APPLICATION:**

**Read entire label before using**

- **TEST A SMALL AREA**, according to application instructions to determine desired results
- Ensure surface is clean and dry.
- Spray / apply Crystal onto a manageable area of approximately 5 to 10 sq. ft. (0.5 m<sup>2</sup> to 1 m<sup>2</sup>)
- Using a synthetic fiber white pad, work the area in a side-to-side motion with a 175 to 300 RPM floor machine
- Add / Mix FM Crystal for consistency and be sure to overlap the sections to achieve an even polish.
- Reapply / continue until the required enhance polish result has been achieved

SHAKE WELL BEFORE USE

#### **▲ CAUTION:**

- **KEEP OUT OF REACH OF CHILDREN**
- Do not take internally.
- Rubber Gloves and eye protection should be worn during application.
- **INHALATION:** Move to fresh air
- **IF INGESTED:** Do not induce vomiting. Drink 1 to 2 glasses of water. Seek immediate medical attention.
- **EYE CONTACT:** Flush thoroughly with water for 15 minutes. If irritation persists, seek medical attention.
- **SKIN CONTACT:** Wash skin with soap and water. Remove contaminated clothing





*Copy right of Floor Medics*